






How To Read Your Meter

Nash 1505/1805/Ricoh1015/1018/2015/4151mf

1. Press the "User Tools" button  to display "1.Counter"
2. Press the "OK" button 
3. The counter reading may be read from the screen.
4. Press the green "Start" button  to print the total count.



User Tools



Counter

```
Counter:Start to Print
Total Pages 3311598
```

Start To Print