




How To Read Your Meter

NashDSC224/232/1224/1232/332/338/ISC1032

1. **Press** the **User Tools/Counter/Inquiry** key
2. **Touch** the **Counter** key to view all the counters
3. Touch the **Print Counter List** key then
press the **Start** key  to print a list of the counters
4. Press the **User Tools/Counter** key to complete the operation



User Tools/Counter/Inquiry



Counter